

Load Break Disconnect Switch
GGLZ1-125A-4000A CHANGEVER LOAD BREAK SWITCH



External Dimension and installation Dimension (Tab) :

Specification	External Dimension and Installation Dimension																		
GGLZ1-1000A-4000A	A	B	C	D	D1	E	J	J1	J2	K	P	R	S	T	ØX	Y	Y1	Y2	Y3
1000A/3	638	312	374	229	340	302	355	106.5	355	220	120	60	56	8	12.5	99	243.5		
1000A/4	758	312	374	289	340	302	473	106.5	473	220	120	60	56	8	12.5	99	243.5		
1250A/3	638	338	374	229	340	302	355	106.5	355	220	120	80	69	8	12.5	99	243.5		
1250A/4	758	338	374	289	340	302	473	106.5	473	220	120	80	69	8	12.5	99	243.5		
1600A/3	638	338	374	229	340	302	355	106.5	355	220	120	80	69	10	12.5	99.5	244		
1600A/4	758	338	374	289	340	302	473	106.5	473	220	120	80	69	10	12.5	99.5	244		
2000A/3	576	455	603	603	700	495	347	88	355	220	120	80	127.5	10	12.5	78.5	225.5	309.5	456.5
2000A/4	696	455	603	603	700	495	467	88	473	220	120	80	127.5	10	12.5	78.5	225.5	309.5	456.5
2500A/3	576	455	603	603	700	495	347	88	355	220	120	80	127.5	10	12.5	78.5	225.5	309.5	456.5
2500A/4	696	455	603	603	700	495	467	88	473	220	120	80	127.5	10	12.5	78.5	225.5	309.5	456.5
3150A/3	576	505	603	603	700	495	467	88	473	220	120	80	127.5	10	12.5	78.5	227.5	309.5	458
3150A/4	696	505	603	603	700	495	467	88	473	220	120	120	152.5	12	12.5	78.5	227.5	309.5	458
4000A/3	576	505	603	603	700	495	347	88	355	220	120	120	152.5		12.5	78.5			
4000A/4	696	505	603	603	700	495	467	88	473	220	120	120	152.5		12.5	78.5			